



Enzunchadora Eléctrica SPZP 2012



An ideal tool for all light duty industrial and commercial packing.



NO METAL SEAL



Light weight
pallet
strapping



Bulk article
strapping



Vertical
strapping



Store away



Corrugated
box strapping

SPZP 2012

Equipo de bajo peso ideal para trabajos de mediana intensidad.
Posee control de tiempo de sellado para distintos tipos de zuncho.
Fácil inserción del zuncho.
Seguro, no opera sin zuncho instalado.

| | |
|----------------|----------------------|
| Voltaje | 220 V 50 Hz |
| Peso | 2.5 kg |
| Medidas (mm.) | 250 x 160 x 140 |
| zuncho | 10 – 16 mm |
| Tensión máxima | 0.55 – 0.65 mm 70 Kg |
| | 0.7 – 1.0 mm. 100 Kg |



Enzunchadora Eléctrica SPZP 2012



Operation indicator "ON"




Lifter "UP"

1 Lift the yellow lifter to "UP" position, **the operation indicator should be "ON" permanently.**



Left hand at rear position

2 Strap around the article, the open end of the loop should be UNDER the strap roll end. **Tighten the loop by hand to a reasonable tightness.** Hold the overlap section of the loop **by left hand at the rear position.**



Slide in direction

3 Lift the yellow lifter and slide the overlap section of the loop into the sealing slot as far as possible. Please make sure that the **open end of the strap is extended out of the slot.** The front and rear strap guider should not press the strap. Release the yellow lifter.



Yellow power button

4 Turn the tighten ratchet **clockwise** to tighten the strap. Hold the tighten ratchet with your whole hand. **Press on the tighten ratchet rubber handle with your thumb.** Press the tension ratchet hard to get extra tension. Tension varies depend on users' arm force output.

5 Press the yellow power button to start sealing and cut off extra length of the strap simultaneously. (Please refer to the user manual for sealing time adjustment.)



Lifter "UP"

6 Lift the yellow lifter to "UP" position and slide the strap out of the sealing slot. Your packing job is done!